

BESI Installation Instructions

Pro Tech II and Pro Tech III Assembly Instructions



1. Unlatch lift and tilt seat cushion forward



2. Unfold unit. Take the cam-wrap strap with the buckle tongue end and 1.5" strap and drop down between the back and cushion.



3. Put cushion in place and latch. Under the cushion, bring forward and connect the 1.5" strap to the front side buckle on front of seat (hold the pad on the seat).



4. Push the Pro-Tech snug against the seat back. Connect the cam-wrap on the back of the seat and adjust to a snug position.



Tall Child
Medium Child
Short Child



5. Adjust torso height to be at or above shoulder height by sliding webbing out and into the correct slot for proper adjustment. Lower slot for shorter, middle slot for medium and upper slot for taller occupants.



6. When using the Pro-Tech II place child in seat. Connect the color coded straps together. Pull the adjustment straps to fit firmly across the hip and shoulder areas. You should not be able to pinch up the webbing. (Pinch Test)

7. When using the Pro-Tech III Place child in seat. Connect the left and right side straps into the center push button buckle, pull the adjustment straps to fit firmly across the hip and shoulder areas. You should not be able to pinch up the webbing. (Pinch Test)

***Warning!** Securement must only be used on school bus seats. Entire seat directly behind must be unoccupied or have secured occupants.

Recommended replacement after 5 years in service.