

National Child Passenger Safety Certification Training Program
Install a Car Seat With an Automatic Locking Retractor



1. Pull webbing fully out of the retractor and hold.



2. Pull the belt through the correct car seat belt path.



3. Buckle it.



4. Apply weight on the car seat and let go of extra webbing.



5. Feed extra webbing back into the retractor.



6. Test for a tight installation of the car seat.

- Grab the seat at the belt path.
- Push and pull it with moderate force – front to back and side-to-side. It should **NOT** move more than 1 inch.