



Our Over the Shoulder Securement

is designed and tested to meet FMVSS-213 standard, along with FMVSS-302 flammability requirements. The Securement must be used with an existing lap belt on a 210 seat frame in order to meet the FMVSS-213 Standard.

Sizes:

- Adult Hi Back
- Adult Low Back
- Child Hi Back
- Child Low Back

The Over the Shoulder Securement is an added way to give extra upper body support when being transported in a school bus.

Assembly Instructions

1. Unbuckle existing seat belt, lift bench seat and insert the tongue part of the buckle end between seat cushion and backrest, leaving the 1 1/2" webbing (crotch strap) lay on the seat cushion.
2. Lay the two shoulder straps over the top on the seat back.
3. Buckle the unit on the backside of the seat back.
4. Place the passenger in the seat; the crotch strap should be between the legs.
5. Thread the lap belt through the first shoulder strap then through the crotch strap loop, then through the remaining shoulder strap and buckle the unit.
6. Buckle chest clip at arm pit level.
7. Pull lap belt snug around hips.
8. Tighten seat mount buckle on back of seat

*Warning! Securement must only be used on school bus seats. Entire seat directly behind must be unoccupied or have secured occupants. **Recommended replacement after 5 years in service.**

BESI, Inc. 9087 Sutton Place West Chester, Ohio 45011 800-543-8222 / 513-874-0579(FAX)